

NO WORK TO BE CARRIED OUT ON UPPER  
FLAT WINDOWS



NEW PANEL

TAKE DOWN AND REPLACE BOTH COLUMNS.

MAKE GOOD.

REPLACE OLD PLINTH.

FORM NEW PLINTH TO MATCH  
PLINTH UNDER BAY WINDOW