



Integrated swift bird boxes should be installed at a minimum height of 3m and in pairs. They are maintenance free boxes therefore need no winter cleaning.



The integrated bat box needs to be placed at a height of 4m. These are permanent structures. They do not need any maintenance once installed. They should be placed near to foraging sites around the proximity of the building development.



The 1FF and 2FN which are to be used on mature trees along the development boundary. These should be installed at 3-6m. They are maintenance free.



Bird boxes should be installed at a height of 3m. Bird boxes should be cleaned at the end of each season, preferably autumn. Ensuring all ticks and old eggs are removed. Any maintenance needed should be carried out at this time.



KEY:

-  1FR Bat Tube
-  Schwegler 1FF bat box
-  Schwegler 2FN Bat box
-  Small hole (26/32mm) bird box
-  Small open fronted nest box
-  Schwegler lightweight swift box type 1A



scheme: New Barn Lane, North Bersted
 client: Bellway
 drawing: Ecological Enhancement Plan
 date: August 2020
 scale: NTS
 drawing no.: BELL22532
 drawn: SP
 checked: DW