

PLANTING SPECIFICATION

General Guidance

All plant handling to be in accordance with the HTA Trading and establishing landscape plants Part 1, Part 1 and Part II (obtainable from the Horticultural Trades Association) and the CPSE publication 'Plant Handling' and all planting to conform to National Planting Specification Guidelines.

The individual setting-out of the plants on site shall be the responsibility of the contractor and should follow closely the locations shown on the detailed planting proposal drawings supplied by the landscape architect. Contractor to ensure that plants are equally spaced within individual planting groups.

Contractor to ensure that smaller plants are located to the front of plant species groups as shown on detailed planting plans.

Contractor shall maintain existing levels around the base of existing trees and shall undertake all planting works occurring within tree protection areas (TPA) in accordance with BS5832:2012. Contractor shall not remove or relocate any tree protection fence without prior consent of the client.

Contractor to check the locations of all underground services, existing and proposed, prior to the excavation of any tree pits or shrub beds and identify any potential conflicts to the client / landscape architect.

All sitings shall be kept to the client / landscape architect at all times, keep the site free from rubbish and debris.

For the duration of the works the contractor shall keep the site free from flytubs weeds as listed in the Weeds Act 1959.

All plants should be supplied at the same size and of the same species as specified in the planting schedules on the landscape proposal plan. Any proposed replacement species or deviation from the planting schedules should be highlighted to and agreed with the client prior to installation.

All plants shall be harden-off at the Contractor's own nursery or at the source prior to planting out.

All field grown and rootballed trees must have been transplanted or undercult in the nursery no less than 18 months prior to supply.

The Contractor shall carry out the while soil and weather conditions are suitable. Planting is not to take place during periods of frost or strong winds.

The contractor is to ensure that adequate watering and weed control is provided at the time of planting.

Any topsoil retained on site in stockpiles for use in planting works is to be stored in accordance with the DEFRA publication: 'Code of practice for the sustainable use of soils on construction sites'

Do not use peat or peat based products.

Prior to planting, planting areas shall be cleared of grass and weed growth physically and/or chemically with a proprietary translocated herbicide and a period of time shall be allowed to elapse as recommended by the manufacturer before commencement of soil preparation for planting.

All plants are to be watered thoroughly before planting stage to ensure rootball is thoroughly soaked prior to final backfilling.

Tree Planting
Generally plant trees in pits with minimum dimensions of:-

- 1000 x 1000 x 700-800mm deep for trees sited in planted areas including grass/shrub areas and rear gardens.

Backfill the pits in layers as specified below from bottom up:-

- Drainage layer
- 200mm layer of compacted inert free draining gravel or pea shingle, wrapped in geo-textile membrane
- 100mm layer of washed medium-course sand to act as binding layer between geotextile and soil.

Topsoil layer

- 400-500mm layer of retained site-sourced topsoil (free from weeds) or imported topsoil (Multi-purpose grade to BS3882:2015, sandy loam), depth dependent on size of rootball.

Depth of topsoil should only be as deep as the rootball of proposed tree to a max. depth of 400-500mm. Should the rootball be larger i.e. 800mm height, then the pit should be increased in depth to suit, but with the difference in depth in the 400-500mm topsoil layer and the drainage layer made up of quality imported free-draining subsoil (to BS8801:2013) to avoid topsoil compaction at depths of greater than 500mm.

Likewise, for smaller trees i.e. feathered trees, with more limited rootballs bare root, the depth of topsoil can be reduced to reflect the surrounding topsoil depths or to a max. topsoil depth of 350mm, with a further layer of site-sourced or imported subsoil (to BS8801:2013) below to create a total depth of growth medium of between 400-500mm to 450-500mm layer of subsoil. Drainage layer should remain as above.

When applicable the use of a small tractor mounted single tire ripper to decompact subsoil layer sufficiently.

Incorporate a soil conditioner/amendment in the form of peat free general-purpose shrub compost or well rotted spent mushroom compost along the planting bed in a 50mm layer at a rate of 300g per m², and incorporate to a depth of 225mm.

Install a proprietary geo-textile weed suppressant membrane onto the surface of the pre-prepared shrub planting beds with minimum 300mm laps. Once planting bed is prepared, dig planting holes for shrubs to be a depth of 200mm and a width of 150mm greater than the source pot size, ensuring that pit walls are loosened to ensure good drainage.

Ensure planting appears random / natural and not formal in accordance with the planting proposal layouts as supplied by the Landscape Architect.

All shrub areas to be dressed with a minimum 75mm mulch layer, consisting of medium chipped tree bark, composted for 2-4 weeks, particle size 15-50mm, laid directly onto weed suppressant membrane.

The contractor shall take the necessary precautions to ensure all shrub areas are protected throughout the establishment period by temporary fencing.

Ornamental Hedge Planting (incl. single species native hedges)

Plant hedges into pre-prepared planting trenches. 500-600mm wide for double rows. Planting strips to consist of topsoil to a depth of 350-400mm, mixed with soil conditioner as specified below.

Topsoil to be either, existing retained site-sourced topsoil (free from weeds) or imported topsoil (Multi-purpose grade to BS3882:2015, sandy loam) or a combination of the two as necessary.

Incorporate a soil conditioner/amendment in the form of peat free general-purpose shrub compost or well rotted spent mushroom compost along planting trench in a 50mm layer at the rate of 300g per m², and incorporate to a depth of 225mm.

Extra-heavy and heavy standard trees shall be staked and supported with a low, double stake consisting of 20x 75mm diameter x min. 2000mm length, rounded timber posts driven into the ground, 600mm above ground level and fixed to the tree by a proprietary rubber tree tie.

Standard trees shall be staked and supported with a low, single stake consisting of 10x 75mm diameter x min. 2000mm length, rounded timber post driven into the ground at 45 degree angle to approx. 450mm above ground level and fixed to the tree by a proprietary rubber tree tie.

Trees shall be installed with proprietary flexible protected irrigation/pole pipe with integral cap. Pipe to be installed encircling equally around rootball to the full depth of planting pit, with the final cap section installed just above ground level and sealed securely in place to the adjacent timber stake.

All trees in grass areas to be protected by min. 225mm high x 12-15mm diam. proprietary plastic stem/wire mulch. When trees have a basal trunk diameter greater than 125mm e.g. semi-mature, then two or more guards shall be joined together using joining tape and then secured in place.

Root Barrier Membranes

When trees are proposed in close proximity to hard paved areas or proposed service runs, a root barrier membrane is to be installed as prescribed below.

For all proposed trees centred in a location within 3m of an adjacent hard standing/footpath or carriageway both the a proprietary root barrier membrane will be installed to protect the hard standing and any underground services located beneath from future damage by tree roots.

Root barrier membrane(s) to be installed on the tree side along the back edge of the kerb / edging restraint to the adjacent hard standing and be to extend a minimum 3m in each direction from a point taken perpendicular from the tree trunk to the kerb/edging face.

Root barrier membranes are to extend to a depth as outlined below:-

- For trees adjacent to hard standings only (no underground services), install 'Root Guard' by GreenBlue Urban (01424 717177) or equal and approved, ribbed root barrier membrane, to a depth of 300mm, the facing tree, joints fixed with joining tape, install 10mm above final surface level of soft landscaping.
- For trees adjacent to hard standings incorporating underground services, install the following dependent on the depth of underground services:
 - For services 450mm deep
 - o 'Renov' 650' by GreenBlue Urban (01424 717177) or equal and approved, ribbed root barrier membrane, to a depth of 600mm, the facing tree, joints fixed with joining tape, install 10mm above final surface level of soft landscaping.
 - For services deeper than 800mm
 - o 'Renov' 2000' by GreenBlue Urban (01424 717177) or equal and approved, ribbed root barrier membrane, to a depth of 1000mm, the facing tree, joints fixed with joining tape, install 10mm above final surface level of soft landscaping.

For locations where a hard standing with or without underground services exists on both sides of the tree e.g. grass verge, then a root barrier is to be installed against both kerbs / edging faces.

For trees located within hard surfaces themselves i.e. surrounded by hard paved surfaces, install 'Root Director' by GreenBlue Urban (01424 717177) or equal and approved, m. 10240, 1400mm x 1400mm x 450mm, plastic root director with integral ribs.

Plant shrubs and groundcover into pre-prepared planting beds consisting of topsoil to a depth of no greater than 400mm, overlying clean, free-draining subsoil. Topsoil to be either, existing retained site-sourced topsoil (free from weeds) or imported topsoil (Multi-purpose grade to BS3882:2015, sandy loam), or a combination of the two as necessary.

Subsoil layer to be fully broken-up to ensure adequate decompaction and adequate free-drainage. For light and non-cohesive subsoils, when ground conditions are reasonably dry, broken thoroughly to a depth of 300mm (400mm for stiff clay / cohesive soils). Remove all stones and debris greater than 50mm, including roots and tufts of grass. Top 50mm of subsoil to be reduced to a medium till substrate for final shaping using a grading blade.

When applicable the use of a small tractor mounted single tire ripper to decompact subsoil layer sufficiently.

Incorporate a soil conditioner/amendment in the form of peat free general-purpose shrub compost or well rotted spent mushroom compost along the planting bed in a 50mm layer at a rate of 300g per m², and incorporate to a depth of 225mm.

Install a proprietary geo-textile weed suppressant membrane onto the surface of the pre-prepared shrub planting beds with minimum 300mm laps. Once planting bed is prepared, dig planting holes for shrubs to be a depth of 200mm and a width of 150mm greater than the source pot size, ensuring that pit walls are loosened to ensure good drainage.

Ensure planting appears random / natural and not formal in accordance with the planting proposal layouts as supplied by the Landscape Architect.

All shrub areas to be dressed with a minimum 75mm mulch layer, consisting of medium chipped tree bark, composted for 2-4 weeks, particle size 15-50mm, laid directly onto weed suppressant membrane.

The contractor shall take the necessary precautions to ensure all shrub areas are protected throughout the establishment period by temporary fencing.

General Planting Maintenance

Refer to CSA/3823/103 Landscape Management Plan for detailed prescriptions

For amenity grass areas only, a pre-seeding fertiliser shall be applied at a rate of 250g/m² approx. 7 days prior to seeding and raked into top surface e.g. Grolight Lawn Establishment fertiliser by Robson Ltd, slow-release granular fertiliser, 7:10:10 NPK, or equal and approved by Landscape Architect.

The area(s) to be seeded between April and October with approved grass seed mix, as specified in the planting schedules at the specified rate. Following seeding, areas are to be hand raked and lightly rolled.

The contractor shall take the necessary precautions to ensure all grass areas are protected throughout the establishment period, with the use of chestnut pale fencing where appropriate.

The contractor shall ensure that all seeded and turf areas are watered fully at the time of installation to the full cultivated depth, and that sufficient subsequent watering is carried out to ensure healthy establishment of the grass seed.

For amenity grass areas only, a pre-seeding fertiliser shall be applied at a rate of 250g/m² approx. 7 days prior to seeding and raked into top surface e.g. Grolight Lawn Establishment fertiliser by Robson Ltd, slow-release granular fertiliser, 7:10:10 NPK, or equal and approved by Landscape Architect.

The area(s) to be seeded between April and October with approved grass seed mix, as specified in the planting schedules at the specified rate. Following seeding, areas are to be hand raked and lightly rolled.

The contractor shall take the necessary precautions to ensure all grass areas are protected throughout the establishment period, with the use of chestnut pale fencing where appropriate.

The contractor shall ensure that all seeded and turf areas are watered fully at the time of installation to the full cultivated depth, and that sufficient subsequent watering is carried out to ensure healthy establishment of the grass seed.

For amenity grass areas only, a pre-seeding fertiliser shall be applied at a rate of 250g/m² approx. 7 days prior to seeding and raked into top surface e.g. Grolight Lawn Establishment fertiliser by Robson Ltd, slow-release granular fertiliser, 7:10:10 NPK, or equal and approved by Landscape Architect.

The area(s) to be seeded between April and October with approved grass seed mix, as specified in the planting schedules at the specified rate. Following seeding, areas are to be hand raked and lightly rolled.

The contractor shall take the necessary precautions to ensure all grass areas are protected throughout the establishment period, with the use of chestnut pale fencing where appropriate.

guy mats to protect the upper surface of the rootball and secured to the base of the tree pit or by use of deadman anchors. Guying supports to be sized in line with the size of the tree as recommended by the manufacturer.

Install a proprietary weed suppressant membrane onto the surface of the pre-prepared shrub planting beds with minimum 300mm laps. Once planting bed is prepared, dig planting holes for shrubs to be a depth of 200mm and a width of 150mm greater than the source pot size, ensuring that pit walls are loosened to ensure good drainage.

Standard trees shall be staked and supported with a low, single stake consisting of 10x 75mm diameter x min. 2000mm length, rounded timber post driven into the ground at 45 degree angle to approx. 450mm above ground level and fixed to the tree by a proprietary rubber tree tie.

Trees shall be installed with proprietary flexible protected irrigation/pole pipe with integral cap. Pipe to be installed encircling equally around rootball to the full depth of planting pit, with the final cap section installed just above ground level and sealed securely in place to the adjacent timber stake.

All trees in grass areas to be protected by min. 225mm high x 12-15mm diam. proprietary plastic stem/wire mulch. When trees have a basal trunk diameter greater than 125mm e.g. semi-mature, then two or more guards shall be joined together using joining tape and then secured in place.

Root Barrier Membranes

When trees are proposed in close proximity to hard paved areas or proposed service runs, a root barrier membrane is to be installed as prescribed below.

For all proposed trees centred in a location within 3m of an adjacent hard standing/footpath or carriageway both the a proprietary root barrier membrane will be installed to protect the hard standing and any underground services located beneath from future damage by tree roots.

Root barrier membrane(s) to be installed on the tree side along the back edge of the kerb / edging restraint to the adjacent hard standing and be to extend a minimum 3m in each direction from a point taken perpendicular from the tree trunk to the kerb/edging face.

Root barrier membranes are to extend to a depth as outlined below:-

- For trees adjacent to hard standings only (no underground services), install 'Root Guard' by GreenBlue Urban (01424 717177) or equal and approved, ribbed root barrier membrane, to a depth of 300mm, the facing tree, joints fixed with joining tape, install 10mm above final surface level of soft landscaping.
- For trees adjacent to hard standings incorporating underground services, install the following dependent on the depth of underground services:
 - For services 450mm deep
 - o 'Renov' 650' by GreenBlue Urban (01424 717177) or equal and approved, ribbed root barrier membrane, to a depth of 600mm, the facing tree, joints fixed with joining tape, install 10mm above final surface level of soft landscaping.
 - For services deeper than 800mm
 - o 'Renov' 2000' by GreenBlue Urban (01424 717177) or equal and approved, ribbed root barrier membrane, to a depth of 1000mm, the facing tree, joints fixed with joining tape, install 10mm above final surface level of soft landscaping.

For locations where a hard standing with or without underground services exists on both sides of the tree e.g. grass verge, then a root barrier is to be installed against both kerbs / edging faces.

For trees located within hard surfaces themselves i.e. surrounded by hard paved surfaces, install 'Root Director' by GreenBlue Urban (01424 717177) or equal and approved, m. 10240, 1400mm x 1400mm x 450mm, plastic root director with integral ribs.

Plant shrubs and groundcover into pre-prepared planting beds consisting of topsoil to a depth of no greater than 400mm, overlying clean, free-draining subsoil. Topsoil to be either, existing retained site-sourced topsoil (free from weeds) or imported topsoil (Multi-purpose grade to BS3882:2015, sandy loam), or a combination of the two as necessary.

Subsoil layer to be fully broken-up to ensure adequate decompaction and adequate free-drainage. For light and non-cohesive subsoils, when ground conditions are reasonably dry, broken thoroughly to a depth of 300mm (400mm for stiff clay / cohesive soils). Remove all stones and debris greater than 50mm, including roots and tufts of grass. Top 50mm of subsoil to be reduced to a medium till substrate for final shaping using a grading blade.

When applicable the use of a small tractor mounted single tire ripper to decompact subsoil layer sufficiently.

Incorporate a soil conditioner/amendment in the form of peat free general-purpose shrub compost or well rotted spent mushroom compost along the planting bed in a 50mm layer at a rate of 300g per m², and incorporate to a depth of 225mm.

Install a proprietary geo-textile weed suppressant membrane onto the surface of the pre-prepared shrub planting beds with minimum 300mm laps. Once planting bed is prepared, dig planting holes for shrubs to be a depth of 200mm and a width of 150mm greater than the source pot size, ensuring that pit walls are loosened to ensure good drainage.

Ensure planting appears random / natural and not formal in accordance with the planting proposal layouts as supplied by the Landscape Architect.

All shrub areas to be dressed with a minimum 75mm mulch layer, consisting of medium chipped tree bark, composted for 2-4 weeks, particle size 15-50mm, laid directly onto weed suppressant membrane.

The contractor shall take the necessary precautions to ensure all shrub areas are protected throughout the establishment period by temporary fencing.

General Planting Maintenance

Refer to CSA/3823/103 Landscape Management Plan for detailed prescriptions

For amenity grass areas only, a pre-seeding fertiliser shall be applied at a rate of 250g/m² approx. 7 days prior to seeding and raked into top surface e.g. Grolight Lawn Establishment fertiliser by Robson Ltd, slow-release granular fertiliser, 7:10:10 NPK, or equal and approved by Landscape Architect.

The area(s) to be seeded between April and October with approved grass seed mix, as specified in the planting schedules at the specified rate. Following seeding, areas are to be hand raked and lightly rolled.

The contractor shall take the necessary precautions to ensure all grass areas are protected throughout the establishment period, with the use of chestnut pale fencing where appropriate.

The contractor shall ensure that all seeded and turf areas are watered fully at the time of installation to the full cultivated depth, and that sufficient subsequent watering is carried out to ensure healthy establishment of the grass seed.

For amenity grass areas only, a pre-seeding fertiliser shall be applied at a rate of 250g/m² approx. 7 days prior to seeding and raked into top surface e.g. Grolight Lawn Establishment fertiliser by Robson Ltd, slow-release granular fertiliser, 7:10:10 NPK, or equal and approved by Landscape Architect.

The area(s) to be seeded between April and October with approved grass seed mix, as specified in the planting schedules at the specified rate. Following seeding, areas are to be hand raked and lightly rolled.

The contractor shall take the necessary precautions to ensure all grass areas are protected throughout the establishment period, with the use of chestnut pale fencing where appropriate.

The contractor shall ensure that all seeded and turf areas are watered fully at the time of installation to the full cultivated depth, and that sufficient subsequent watering is carried out to ensure healthy establishment of the grass seed.

For amenity grass areas only, a pre-seeding fertiliser shall be applied at a rate of 250g/m² approx. 7 days prior to seeding and raked into top surface e.g. Grolight Lawn Establishment fertiliser by Robson Ltd, slow-release granular fertiliser, 7:10:10 NPK, or equal and approved by Landscape Architect.

The area(s) to be seeded between April and October with approved grass seed mix, as specified in the planting schedules at the specified rate. Following seeding, areas are to be hand raked and lightly rolled.

The contractor shall take the necessary precautions to ensure all grass areas are protected throughout the establishment period, with the use of chestnut pale fencing where appropriate.

FOR LEAP 1 PLAY AREA
PROPOSALS REFER TO
CSA/3823/112

FOR PUBLIC OPEN SPACE
PROPOSALS REFER TO
CSA/3823/107-110

REFER TO CSA/3823/102

REFER TO CSA/3823/102

FOR PUBLIC OPEN SPACE
PROPOSALS REFER TO
CSA/3823/107-110

LEGEND

APPLICATION BOUNDARY

EXISTING TREES / VEGETATION

Softworks

SEMI-MATURE TREE

EXTRA HEAVY STANDARD TREE

STANDARD TREE

ORNAMENTAL HEDGE PLANTING

NATIVE HEDGE PLANTING

ORNAMENTAL SHRUB / HERBACEOUS / GRASS PLANTING

CLIMBING SHRUB PLANTING

AMENITY GRASS SEEDING - 'A22 (Low Maintenance)' seed mix by

Amend Seeds Ltd or equal and approved. 50g/m², overseeded rate: 20g/m².

AMENITY GRASS TURF - 'Medallion' turf by Rolown or equal and approved.

SWALE SEEDING - 'A16' (Reclamation)' seed mix by Gromed Seeds Ltd or equal and approved. 50g/m², overseeded rate: 20g/m².

GRAVEL - See single laid to a depth of 100mm over non-biodegradable geotextile membrane. Finished level to be 20mm below adjacent ground level

Notes

- Refer to CSA/3823/103 for Plant Schedule;
- Refer to CSA/3823/104-106 for Hard Landscape Proposals;
- Refer to CSA/3823/107-110 for Public Open Space Landscape Proposals.

Date	By	Description
13/09/19	AL	POS updated for content
12/07/19	AL	POS updated for content
11/04/19	AL	Amended for new tree collection points
09/04/19	AL	Link to Tree Lane amended
08/04/19	AM	Link to Tree Lane amended
11/02/19	AM	Revised to show revised POS content
11/02/19	AL	Revised to show revised POS content
11/02/19	AL	Revised to show revised POS content

Client: Soft Landscape Proposals

Sheet: 1 of 3

Project: Land East of 1st Lane, Walberton

Scale: 1:250 @ A0

Date: October 2018

Drawing No: CSA/3823/101

Client: Linden Homes

Scale: 1:250 @ A0

Date: October 2018

Drawing No: CSA/3823/101

Client: Linden Homes

Scale: 1:250 @ A0

Date: October 2018

Drawing No: CSA/3823/101

Client: Linden Homes

Scale: 1:250 @ A0

Date: October 2018

Drawing No: CSA/3823/101

Client: Linden Homes

Scale: 1:250 @ A0

Date: October 2018

Drawing No: CSA/3823/101

Client: Linden Homes

Scale: 1:250 @ A0

Date: October 2018

Drawing No: CSA/3823/101

Client: Linden Homes

Scale: 1:250 @ A0

Date: October 2018

Drawing No: CSA/3823/101

Client: Linden Homes

Scale: 1:250 @ A0

Date: October 2018

Drawing No: CSA/3823/101

Client: Linden Homes

Scale: 1:250 @ A0