




Senario
Convalescent

Wellesley
Court

A L B E R T
R O A D

R O A D

Hatherleigh
L'Idelle

Alia

Romney

Canterbury

Eastlands

Shorebank

Surrey
Lodge

Cambridge House
(Children's Holiday Home)

Roman Catholic
Church of Our Lady
of Sorrows

The Service
Priory

Catholic
Club

Sidlaw-Terrace
CLARENCE

Alexandra-Terrace
T E E R T + 17
R O A D

War
Memorial

Town Hall

Fire Station

St Albans

Surgey

La Mancha

Teneriffe

Westbury

Miramar

Wellsmead

BM 19.75

Head Post Office

SUSSEX ROAD

T O W N
B M 18.65
B L E

Car Park


CLOCK TOWER

The White
House

Bradenham House

Crispin House

ridge



936

SUSSEX WEST EURO CONST

937

938

ARUNDEL CO CONST

939

SZ 9398 NE

CONVERSION SCALE

METRES-FEET

Metres	10	0	20	40	60	80	100	120	140	160	Metres
Feet	50	0	100	200	300	400	500	600	700	800	Feet

1 metre = 3.2808 feet 1 foot = 0.3048 metre

BOUNDARIES

ENGLAND AND WALES	SCOTLAND
County	Region or Islands Area
District	District
London Borough	Not shown
Civil Parish (England)	
Community (Wales)	
Electoral Division	Electoral Division
Ward	Ward
Constituency (County, Borough or European Assembly)	Constituency (County, Borough or European Assembly)

Concoident boundaries are shown by the first appropriate symbol above e.g. Boro. Const and ED Bdy.

For Ordnance Survey purposes County Boundary is deemed to be the limit of the parish structure whether or not a parish area adjoins.

NATIONAL GRID REFERENCE

The grid lines form part of the National Grid and are at 100 metre intervals defining the position of a point to within 10 metres proceed as follows:

- 1 Take the two letters preceding the sheet number
- 2 Take the west edge of the grid square in which the point lies and read the figures opposite this line on the north or south margin. Estimate tens of metres from the grid line to the point (distance). The resulting four figure number is the Easting.
- 3 Take the south edge of the grid square in which the point lies and read the figures opposite this line on the east or west margin. Estimate tens of metres from the grid line to the point (distance). The resulting four figure number is the Northing.
- 4 The full ten metre reference is given by writing first the letters, followed by the Easting and then by the Northing.

For further information see 'An Introduction to the Projection for the National Reference System'.

Boundary markings

BB	Base of Bank	CR	Centre of Road, etc	FF	Face of Fence	TB	Top of Bank
CB	Centre of Bank	CS	Centre of Stream, etc	FW	Face of Wall	Th H	Track of Hedge
CCS	Centre of Covered Stream	Del	Defaced	RH	Root of Hedge	Th S	Track of Stream
CD	Centre of Drain, etc	EK	Edge of Kerb	SR	Side of River, etc	Und	Unfenced

One grid square on this plan represents one hectare. To convert hectares to acres multiply by 2.47.